












Standard Zone Panel – Brooder Controls

Ignition Type			
Manual Ignition Brooders	Part # 09688-D		Control: standard control 09Brooder Capacity: 14 (LP), 8 (NG) Electrical: 120V / 60Hz / 1 Weight: approximately 12 lbs.
	Part # 09856-D		Control: standard control Brooder Capacity: 40 (LP & NG) Electrical: 120V / 60Hz / 1 Weight: approximately 12 lbs.
	Part # 09959		Control: house environmental control – on/off Brooder Capacity: 40 (LP & NG) Electrical: 120V / 60Hz / 1 Weight: approximately 12 lbs. Includes: sensor bracket 
	Part # 22553		Control: house environmental control – dual stage Brooder Capacity: 40 (LP & NG) Electrical: 120V / 60Hz / 1 Weight: approximately 12 lbs. Includes: sensor bracket 



Auto Modulating Zone Panel – Brooder Controls

<p>Ignition Type</p> <p>Manual Ignition</p>	<p>Part # 28543</p>		<p>Control: house control</p> <p>Brooder Capacity: 24 brooders (LP & NG)</p> <p>Electrical: 24 VDC Power Supply and a 0-10 VDC control signal from the house control</p> <p>Weight: approximately 12 lbs.</p> <p>Includes: sensor bracket</p> 
	<p>Part # 28564</p>		<p>Control: SmartBox™ control</p> <p>Brooder Capacity: 24 brooders (LP & NG)</p> <p>Electrical: 24 VDC power supply and pwm control signal</p> <p>Weight: approximately 9 lbs.</p> <p>Includes: sensor bracket</p> 
	<p>Part # 29537</p>		<p>Control: house environmental control</p> <p>Brooder Capacity: 40 brooders</p> <p>Electrical: 24 VDC Power Supply and a 0-10 VDC control signal from the house control</p> <p>Weight: approximately 12 lbs.</p> <p>Includes: sensor bracket</p> 
<p>Spark Ignition</p>	<p>Part # 26487</p>		<p>Control: house envionrmental control</p> <p>Brooder Capacity: 24 brooders (LP & NG)</p> <p>Electrical: 24 VDC Power Supply and a 0-10 VDC control signal from the house control</p> <p>Weight: approximately 5 lbs.</p> <p>Includes: sensor bracket</p> 