

INSTALLATION INSTRUCTIONS



Journeyman 360 Replacement Fan Switch

View these instructions online at www.lbwhite.com

- Before installing the new fan switch, assemble the fan switch, gasket, and heat sink as shown in FIG. 1
- Pressed the heat sink completely onto the fan switch base.
- Failure to properly installed the heat sink to the fan switch will result in the main fan motor to cycle unnecessarily.
- Ensure the fan switch is set to 110°F (43°C). See Fig. 2.
- Adjustment of the fan switch may be required when operating the heater in extreme cold temperature.
- The necessary adjustment will depend on the ambient air temperature.

FIG. 1

HOLE MUST BE ALIGNED WITH THIS FACE HEAT SINK PRESSED COMPLETELY ONTO SWITCH




FIG. 2



WORLD PROVIDER - INNOVATIVE HEATING SOLUTIONS

150-133774 REV.A

411 Mason Street, Onalaska, WI 54650 • 800-345-7200 • 608-783-5691 • 608-783-6115 (fax) • www.lbwhite.com

INSTALLATION INSTRUCTIONS



Journeyman 360 Replacement Fan Switch

View these instructions online at www.lbwhite.com

- Before installing the new fan switch, assemble the fan switch, gasket, and heat sink as shown in FIG. 1
- Pressed the heat sink completely onto the fan switch base.
- Failure to properly installed the heat sink to the fan switch will result in the main fan motor to cycle unnecessarily.
- Ensure the fan switch is set to 110°F (43°C). See Fig. 2.
- Adjustment of the fan switch may be required when operating the heater in extreme cold temperature.
- The necessary adjustment will depend on the ambient air temperature.

FIG. 1

HOLE MUST BE ALIGNED WITH THIS FACE HEATSINK PRESSED COMPLETELY ONTO SWITCH




FIG. 2



WORLD PROVIDER - INNOVATIVE HEATING SOLUTIONS

150-133774 REV.A

411 Mason Street, Onalaska, WI 54650 • 800-345-7200 • 608-783-5691 • 608-783-6115 (fax) • www.lbwhite.com