

INSTALLATION INSTRUCTIONS



Volt Hanging Kit

View these instructions online at www.lbwhite.com

Kit Contents:

DESCRIPTION	QTY.
Installation Instructions	1
Hanging Kit	1
Screws, Cap, Hex	4
Washers, Lock (Not Available on Volt 1.5)	4
Plates, Clamping	2

Kits:

Volt 1.5	500-133965
Volt 3	500-133975
Volt 6	500-133980

Tools required:

Volt 1.5

- 5/16 in. open ended wrench or socket/ratchet

Volt 3 & 6

- 7/16 in. open ended wrench or socket/ratchet

Qualifications for installation of the kit:

- You must be able to read and understand these instructions.
- You must be properly trained and have sufficient experience in servicing heaters and be capable of testing the heater for proper operation.

General information:

- The following instructions provide information for the assembly of the hanging kit to the Volt heaters.
- Read all instructions carefully before beginning assembly and installation.
- Allow the heater to cool down or in cold condition before installing the hanging kit.
- Assistance of another person will be required when installing the heater with the hanging kit to the ceiling.
- Tighten all screws securely.


Preparation:

- Remove all components from box to ensure all necessary parts have been received.
- Check all packing material carefully for damage or for parts that may have come loose inside the carton during shipment.
- Unplug the heater from its electrical supply.

Installing Hanging Kit to Heater:


1. Place the heater and the hanging kit on a clean flat surface.
2. Loosen the rear clamp plate screws. See Fig. 1.
3. Remove the front clamp plate screws and lock washers, if applicable.

FIG. 1



5. Slide the hanging kit onto the heater top case. See Fig. 2.
6. Install the front clamp plate to the hanging kit as shown in Fig. 2.
7. Center the hanging kit on the heater case top.
8. Tighten all screws securely.

FIG. 2



Hanging Heater to the Ceiling:

1. With the assistance of another person, lift the heater and align ceiling bracket slots with ceiling joists.
2. Secure the ceiling bracket to the ceiling joists with 2-1/2 inch construction screws (not provided).
DO NOT use anchors to support the hanging kit.
3. Secure a minimum of 4 points on the ceiling bracket to the ceiling joists. See Fig. 3.
 - For best support results, position the screws as closed to the heater center as ceiling joists allow.
4. Loosen adjusting knob and angle heater to desired angle.
5. Tighten the adjusting knob.

FIG. 3



Service

Contact your local L.B. White dealer for replacement parts and service. You may also call the L.B. White Co., LLC at U.S. & Canada: 1-800-345-7200, Overseas: 001-608-783-5691 assistance, or email us at customerservice@lbwhite.com.

Be sure that you have either the heater model or serial number when calling.



WORLD PROVIDER - INNOVATIVE CLIMATE SOLUTIONS

411 Mason Street, Onalaska, WI 54650
800-345-7200 • 608-783-5691
608-783-6115 (fax)

www.lbwhite.com

150-133960 REV.A