

L.B.WHITE


by **MODINE**



Air Inlet Transition Kit



Motorized Inlet Shutter



Exhaust Shutter



Shutter Exhaust Fan

HORTICULTURAL VENTILATION

- Easy installation
- Kits come preassembled
- Includes mounting specifications

All heaters require ventilation for proper operation. The **Therma Grow™** is no different. The **Therma Grow™** requires 2.5 CFM per 1000 Btu/h of air exchange. For a **Therma Grow™** 220, this translates to 550 CFM of air exchange for an indoor installation, and 220 square inches of exit area for an outside mount. Similarly, a **Therma Grow™** 120 requires 300 CFM per indoor mount, and 120 square inches of exit area per outdoor mount. To make installation easy, L.B. White offers several preassembled kits that include application specific mounting & ventilation equipment. See chart on reverse side for required air exchange for maximum performance.

See Figs. B and C

See Fig. A

	Fan Diameter	Required Wall Opening	Motor HP	Volts	Phase	Ship Wt. (Lbs)
INDOOR KITS						
#25995 - Therma Grow™ 120						26
Install and Vent Kits Include: Motorized Inlet Shutter	-	13 1/2" x 13 1/2"	-	115	1	
Shuttered Exhaust Fan	10	10 1/4" x 10 1/4"	1/30	115	1	
Air Inlet Transition Kit	-	-	-	-	-	
Air Inlet Hood	-	-	-	-	-	
Eyebolts and Chains	-	-	-	-	-	
#25985 - Therma Grow™ 220						27
Motorized Inlet Shutter	-	15 1/2" x 15 1/2"	-	115	1	
Shuttered Exhaust Fan	10	10 1/4" 10 1/4"	1/30	115	1	
Air Inlet Transition Kit	-	-	-	-	-	
Air Inlet Hood	-	-	-	-	-	
Eyebolts and Chains	-	-	-	-	-	
OUTDOOR KITS						
#24690 - Therma Grow™ 120						40
Exhaust Shutter	-	10 1/2" x 10 1/2"	-	-	-	
Outdoor Mount Kit	-	-	-	-	-	
#24688 - Therma Grow™ 220						50
Exhaust Shutter	-	14 1/2" x 14 1/2"	-	-	-	
Outdoor Mount Kit	-	-	-	-	-	

Minimum Air Exchange Requirements	Therma Grow™ 120 or 120 Plus	Therma Grow™ 220 or 220 Plus
Indoor Installation (cu. ft per min)	300 CFM	550 CFM
Outdoor Installation (sq. inches of exit area)	120 in ²	220 in ²

Fig. A - Outdoor Ventilation Kit




Fig. B - Indoor Ventilation Kit





Fig. C - Indoor Mount with Air Inlet Transition Kit



Indoor Mount with Air Inlet Transition Kit



Innovative Climate Solutions

411 Mason Street, Onalaska, WI 54650
 800 345 7200 (toll free) or 608 783 5691
 608 783 6115 (fax)
 info@lbwhite.com | www.lbwhite.com

CA RESIDENTS:
WARNING
 Cancer and reproductive harm. See
www.P65Warnings.ca.gov.

© 2025 L.B. White Company
 All rights reserved.
 All specifications are subject
 to change without notice.