INSTALLATION INSTRUCTIONS



Tube Heaters

Extension Panels Kit 500-134816

View these instructions online at www.lbwhite.com

Kit Contents:

DESCRIPTION	QTY.
Installation Instructions	1
* Extension Panel, 5 ft.	8
* Clips	7

* The kit includes eight extension panels and seven clips, intended for a 40-foot tube heater. If the tube heater is shorter then 40 feet, discard any unused panels or clips.

Tools required:

No tools required

NOTE: Not to be used on Oval-U 100 tube heater models

Qualifications for installation of the kit:

- You must be able to read and understand these instructions.
- You must be properly trained and have sufficient experience in servicing heaters and be capable of testing the heater for proper operation.

General information:

- \bullet The following instructions outline the installation process for extension panels onto the shrouds when tube heaters are mounted at a 45° angle.
- Read all instructions thoroughly before beginning assembly and installation.
- Ensure the heater is cool or in a cold condition before installing the extension panel kit.


Preparation:


- Remove all components from box to ensure all necessary parts have been received.
- · Unplug the heater from its electrical supply.
- Rotate the hanging chain to the 45° angle slot on the shroud hangers.

www.lbwhite.com

Installing Extension Panel to the Shroud:


- Insert the first extension panel fully into the initial shroud section, as shown in Fig. 1.
 Ensure the hangers align properly within the opening of the extension panel.
- 2. Bend the panel to a 45° angle, or to the desired angle as needed. Refer to Fig. 2 for guidance.






Installing Extension Panel to the Shroud (continue):

- 3. Repeat the previous steps for each remaining extension panels along the length of the tube.
- 4. Overlap each new extension panel with the preceding one by 1-2 inches, or as needed for proper fit.
- 5. Secure the overlapping panels using the provided clips as illustrated in Fig. 3.



Completion:



Service

Contact your local L.B. White dealer for replacement parts and service. You may also call the L.B. White Co., LLC at U.S. & Canada: 1-800-345-7200, Overseas: 001-608-783-5691 assistance, or email us at customerservice@lbwhite.com.



WORLD PROVIDER - INNOVATIVE CLIMATE SOLUTIONS

411 Mason Street, Onalaska, WI 54650 800-345-7200 • 608-783-5691 608-783-6115 (fax)

www.lbwhite.com