

ASSEMBLY and INSTALLATION INSTRUCTIONS



Ducting Kit - 30 ft. Kit Part No. 500-23871

View these instructions online at www.lbwhite.com

Kit Contents:

Description	Quantity
Instructions	1
Duct (8 in. dia. x 30 ft.)	1
Clamp	1
Duct Adapter	1


Tools Required:

-- Standard Screwdriver

A. Assembling Duct

1. Partially unroll the duct until several sets of holes are visible. Position the duct so holes are pointed up and to the interior of tent. See Fig. 1. (Duct is shown inflated for clarity of viewing holes.)

FIG. 1




2. Pull the duct over the adapter and secure in place with duct clamp. See Fig. 2.

FIG. 2



B. Installing Duct to Distribution Box

1. Attach duct assembly to outlet of air distribution box. Tabs on collar lock into slots at box outlet. See Fig. 3.

FIG. 3

2. Extend duct to full length along tent side wall. Eliminate any kinks.
3. Install panel onto unoccupied hole of distribution box. See Fig. 3.

C. Completion

1. Connect the heater to its electrical and gas supplies. Open the fuel supply valve. Start the heater. The booster box will start and ducts will inflate.
2. Once the ducts inflate, anchor or stake the duct clasps to prevent duct movement during use. See Fig. 4.
3. Refer to General Installation Instructions for completed view of air distribution kit.

FIG. 4

Service

Contact your local L.B. White dealer for replacement parts and service. You may also call the L.B. White Company, LLC at U.S. & Canada: 1-800-345-7200, Overseas: 001-608-783-5691 assistance, or email us at customerservice@lbwhite.com.

Be sure that you have your heater model number and configuration number when calling.



**WORLD PROVIDER - INNOVATIVE
HEATING SOLUTIONS**

411 Mason Street, Onalaska, WI 54650

800-345-7200 • 608-783-5691

608-783-6115 (fax)

www.lbwhite.com