

INSTALLATION INSTRUCTIONS



Mini-T Hanging Display Kit Kit: 500-134469

View these instructions online at www.lbwhite.com

Kit Contents:

DESCRIPTION	IMAGE	QTY.
Instruction, Installation		1
Display Base		2
Magazine Holder Assembly		1
1/2 in. x 26 in. Black Pipe		6
1/2 in. Pipe Coupler		3
1/2 in. Pipe Elbow		2
Long Hanger with Quick Link		1
Short Hanger with Quick Link		1

Tools required:


- No tools are required, but a pipe or channel-lock wrench can be used for a more secure tightening of the pipe assembly.

General Information:

- The following instructions provide information for the assembly of the L.B. White Mini-T Hanging Display Kit.
- Read all instructions carefully before beginning.
- Mini-T heater not included with kit.
- Tighten all connection securely.


Assemble Pipe Hanging Frame:

- Assemble the hanging kit as illustrated below.
 - Ensure all pipe connections are securely tighten before continuing.
- A. Install one 26 in. pipe onto the display base plate.
 - B. Connect a second pipe to the first using a coupler.
 - C. Slide the magazine holder assembly down the pipe and secure it at the desired height.
 - D. Attach an elbow to the top of the second pipe, rotate it 90°, and connect a third pipe to the elbow.
 - E. Insert the long hanger with a quick link through the third pipe.
 - F. Connect the fourth pipe to the third using a coupler.
 - G. Insert the short hanger with a quick link through the fourth pipe.
 - H. Attach another elbow to the fourth pipe, rotate it 90° downward, and connect the fifth pipe to the elbow.
 - I. Connect the sixth pipe to the fifth using a coupler.
 - J. Attach the final display base plate to the end of the sixth pipe and secure it by rotating the base counterclockwise onto the pipe.



Hanging the Mini-T to the Display Kit:

1. Open both quick links.
2. Attach the Mini-T's bracket and hanger to the quick links.
3. Close both quick links to secure the unit and prevent accidental unhooking.



Service

Contact your local L.B. White dealer for replacement parts and service. You may also call the L.B. White Co., LLC at U.S. & Canada: 1-800-345-7200, Overseas: 001-608-783-5691 assistance, or email us at customerservice@lbwhite.com.

Be sure that you have either the heater model or serial number when calling.



**WORLD PROVIDER - INNOVATIVE
CLIMATE SOLUTIONS**

411 Mason Street, Onalaska, WI 54650
800-345-7200 • 608-783-5691
608-783-6115 (fax)

www.lbwhite.com